

08855342

UPOZORNĚNÍ: Množství zobrazovaných údajů se může lišit dle typu diagnostikovaného vozidla.

Návod k použití Čidlo zapojte do OBDII portu Vašeho vozu. Otočte klíčkem do polohy 2. V Bluetooth v telefonu/tabletu vyhledejte nové zařízení označené jako OBDII. Spárujte. Kód pro párování je 1234. Pro správnou funkci je zapotřebí mít instalovaný některý z níže uvedených programů.

Podporovaný software (Android / iOS / Windows Phone):

- Torque / Torque LITE
- OBD Doctor
- Scantool.net
- Engine Check
- GM Mode 22 Scan Tool by Terry
- OBD Gauge for PalmOS and Pocket PC by Dana Peters
- OBD Logger by Jonathan Senkerik
- OBD-II ScanMaster by Wladimir Gurskij (ScanMaster 3.52 – local copy)
- obd2crazy.com
- OBD2 Scantool by Ivan Andrzejewski
- OBDII for ELM322 by David Huffman
- pyOBD by Donour Sizemore for MacOSX and Linux
- RDDTC by Pete Calinski
- Real Scan by Brent Harris
- ScanTest for Pocket PC by Ivan Ganev aka a-ser
- wOBD by WDT
- easy OBD
- DigiMoto
- PCMSCAN

TIPA, spol. s r.o.

Sadová 2749/42, 74601 Opava, Česká republika

www.tipa.eu